Owner's Manual

GENERAL



CASABLANCA® FAN COMPANY

CONTENTS

INTRODUCTION 3
MOUNTING RECOMMENDATIONS 4
FAN INSTALLATION 5
OUTSIDE USA (EXCLUDING MODELS ENDING IN 'E') FAN INSTALLATION 10
CONTROL FEATURES:
3-SPEED OPERATION 12
INTELI•TOUCH OPERATION 14
VERSA•TOUCH OPERATION 17
COMFORT•TOUCH OPERATION 19
TROUBLESHOOTING 23

READ AND SAVE THESE INSTRUCTIONS

SAFETY FIRST

Safety and the proper operation of your Casablanca fan both require a thorough knowledge of the product and proper installation; therefore, before attempting to install and operate your Casablanca fan, read this owner's manual completely and carefully. Retain this manual for future reference.

CAUTION: To avoid possible electrical shock, make certain that electricity is turned off at the circuit breaker or fuse box before attempting any installation procedure.

BEFORE YOU START

- All wiring must be in accordance with the National Electric Code ANSI/NFPA 70-1993 and the appropriate local electrical codes. The National Electric Code requires proper grounding as a precaution against electrical shock. A qualified electrician should be consulted if you are unsure.
- This fan is designed to be installed on an existing electrical outlet box. The outlet box must be UL Listed for ceiling fan installations, if it is not, a new box must be installed. Casablanca extension poles are available for sloped or high ceiling installations.
- This ceiling fan requires a grounded electrical supply of 120 VAC, 60 Hz and a minimum 15 amp circuit. The maximum current requirement for the fan with light fixture is 3.8 amps. The fan uses about 1 amp or 100 watts. Maximum light current is 2.8 amps or 340 watts of lighting.
- Where wire nuts are employed, be sure all bare wires are within the connectors. When installing the canopy hatch, make sure all wires are within the canopy and that no wires are being pinched.

For best performance and for your warranty to be valid,
use only genuine Casablanca blades, light fixtures, and accessories.

SAFE USE

- The blades in each pack are matched for equal weight to assure smooth fan operation. If more than one fan is being installed, be careful not to mix blades from different cartons.
- Inspect the contents of your carton for possible shipping or handling damage and report any such damage directly to your authorized Casablanca dealer.
- It is always a good idea to have an assistant to help with the installation.
- When cleaning, painting, or working near your fan, be very careful of the fan and blades. Always turn the power OFF to the ceiling fan before servicing it, working on it, or replacing light bulbs.
- Never insert anything into the path of the fan blades while the fan is in operation.
- Never install a fan over a pool or spa.
- Never operate a fan that has been damaged in any way. Contact Casablanca Fan Company by calling 1-888-227-2178, or contact your local authorized Casablanca dealer for assistance in obtaining service.

FUSE BOX
(REMOVE FUSE FOR THE CIRCUIT YOU WILL BE WORKING ON)



CIRCUIT BREAKER
(TRIP BREAKER FOR THE CIRCUIT YOU WILL BE WORKING ON)





CAUTION: MOUNT WITH THE LOWEST MOVING PARTS AT LEAST 2.5 METRES ABOVE FLOOR OR GRADE LEVEL.
ATTENTION: INSTALLER DE SORTE QUELES PIÈCES INFÉRIEURES SOIENT À AU MOINS 2.5 MÈTRES AU-DESSUS DU PLANCHER OU DU SOL.

MOUNTING RECOMMENDATIONS

Before mounting your Casablanca fan, read the following helpful recommendations. The location of the fan, air circulation, and fan size are all important factors to consider before installation.

Location

Ceiling fans have practical uses in almost every room in your home. We suggest you follow these mounting recommendations as you decide where to install your Casablanca fan.

- For safety reasons, the fan blades must be a minimum of 7' above the floor.
- Do not locate the fan in a doorway or above a swinging door.
- In any installation, the tips of the blades must be at least 18" from the wall in order to provide sufficient clearance for the blades.
- In bedrooms, fans work best when mounted above the foot of the bed.
- In low ceiling locations, our optional Low Ceiling Adaptor (LCA—available at extra cost) can be used to gain 3½" on certain fan models.
- Over pool tables, be sure to provide plenty of clearance to avoid damage from pool cues.
- In kitchens be sure to allow for open cupboard doors to clear the fan blades.
- Do not install a fan close to, or over, a pool or spa. High humidity combined with corrosive gases will destroy the finish and warp the blades.



Fan Size

Variable fan speed capability permits the use of a full-size 52" fan even in smaller rooms. For very large rooms, two fans may be needed.

SLOPED CEILING INSTALLATIONS

Suggested Extension Pole Lengths	
Ceiling Height	**Pole Length**
8'	Standard
8' 6"	Standard
9'	6"
9' 6"	12"
10'	12"
11'	18"
12'	24"
13'	36"
14'	48"



When to Use Extension Poles

For best performance and best appearance, an extension pole should be used with your Casablanca fan when installing on high (cathedral) ceilings or sloped ceilings. Casablanca offers standard poles in increments of 6" up to 5'. Custom poles are available in lengths up to 10'. See your Authorized Casablanca Dealer for details.

NOTE: *Fan may wobble or vibrate if pole length is not long enough and inside blade is too close to downslope or side wall. Extending pole length will usually solve problem.*



EXAMPLE 1
This slope is less than 32˚.
It is OK to install your fan.

EXAMPLE 2
This slope is 32˚. This is the maximum slope that will allow the fan to hang straight down. It is OK to install your fan.

EXAMPLE 3
This slope is more than 32˚.
Your fan will not hang straight down, an adaptor is necessary. Contact your local Authorized Casablanca Dealer in regards to purchasing a "Slope Ceiling Adaptor."

Calculation of 32

Use the tear-off *Ceiling Angle Template* card inserted in the back of this manual, it provides you with a simple 'go' or 'no-go' for installing your fan on a sloped ceiling.

INSTALLATION INSTRUCTIONS

Unpacking: Before assembling and installing your ceiling fan, remove all parts from the shipping cartons and check them against the parts listed here. Before discarding packaging material, be certain that all parts have been removed.

NOTE: *Only one set of blade holders is supplied. Depending on the fan model and series they will be either the Commodore Style, the Center Style, the Badge Style with matching badges, or the Standard Style blade holder.*

PERMA•LOCK™ HARDWARE



LOCKING BOLT (MOTOR COUPLING)



DOWNROD & BALL ASSEMBLY

FAN PREPARATION

IMPORTANT SAFETY INFORMATION!
BEFORE STARTING THE INSTALLATION OF YOUR CEILING FAN, INSTALL THE THREADED DOWNROD INTO THE MOTOR COUPLING AND LOCK THE ASSEMBLY

Prepare for fan installation as follows:
Step A. Route the wires from the motor through the Perma•Lock™ downrod and ball assembly.

Tip: The downrod has a tapered thread that is designed to lock completely when correctly installed.

Step B. Thread the downrod into the motor coupling until it stops turning, this will take at least four and a half full turns.
Step C. Securely tighten the locking bolt to ensure safe operation of your fan.

CAUTION: Failure to fully lock in the downrod before securely tightening the locking bolt may cause the fan to separate from the downrod during normal operation!



CEILING HARDWARE



CROSSBAR MOUNTING BRACKET

WIRE NUT (4)

ADDITIONAL HARDWARE



$2^{1}/_{4}$† x 8-32 ROUND HEAD SCREWS (2)

1† x 8-32 ROUND HEAD SCREWS (2)

FLAT WASHER (2)

GETTING STARTED

Installing a New Ceiling Fixture Outlet Box
If you do not have an existing fixture located where you wish to place your Casablanca fan, an approved ceiling fixture outlet box must be installed and wired.

Warning: To reduce the risk of fire, electrical shock, or personal injury, mount to outlet box marked acceptable for ceiling fan support using the mounting hardware provided with the outlet box.

Using Existing Ceiling Fixture Outlet Box
After turning the power OFF at its source (either circuit breaker or fuse box), lower the old fixture and disconnect the wiring. Check the ceiling fixture outlet box to be sure that it is marked '*Approved for ceiling fan mounting*'. If it is not, a new box must be installed.

CROSSBAR MOUNTING BRACKET INSTALLATION

NOTE: FOR INSTALLATION OUTSIDE USA (EXCEPT MODELS ENDING IN 'E') USE THE HANGING INSTRUCTIONS ON PAGE 8.

Proceed with installation as follows:
Step 1. Route the wires from the ceiling outlet box through the crossbar mounting bracket center hole. Attach the bracket, with ground wire and ridges down, to the ceiling fixture outlet box with the mounting hardware included with the outlet box.

Tighten the screws firmly by ***hand*** only, being careful not to bend the bracket by over tightening.

CAUTION: To reduce the risk of personal injury, use only the mounting hardware provided with the approved outlet box to install the crossbar mounting bracket.



CANOPY HARDWARE





CANOPY INSTALLATION

Step 2. Attach the canopy to the crossbar mounting bracket with three of the 8-32 x $2^{1}/_{4}$† long canopy screws and canopy lock washers. Tighten the screw firmly by ***hand*** only.

NOTE: *On sloped ceilings, align the canopy opening towards the top or room peak.*



HANGING THE FAN

Step 3. To hang the fan body in the canopy, hold the fan body firmly and insert the ball into the canopy opening. Check that no wires were pinched. Rotate the fan body until the slot in the nylon ball fits into the pin opposite the canopy opening.

NOTE: Independent control of the light fixture using a W-8 requires an additional power wire run from the wall switch to the fan. See Page 10 for wiring.



CANOPY ELECTRICAL CONNECTIONS

Step 4a. Attach the fan wires to the ceiling fixture outlet box wiring by twisting the bare ends of the wires together and then securing with a wire nut. Test that the connection is secure by pulling on the wire nut. Connect in this order:

Step 4b. Pull Chain or W-4 Wiring Connections

- GREEN leads from mounting plate and fan to GROUND conductor of power source. Secure with wire nut.
- WHITE wire from fan to white NEUTRAL wire in ceiling fixture outlet box. Secure with wire nut.
- BLUE wire and BLACK power wire from fan to BLACK power wire in ceiling outlet box. Secure with wire nut.

Step 4c. W-8 Wiring Connections

- GREEN leads from mounting plate and fan to GROUND conductor of power source. Secure with wire nut.
- WHITE wire from fan to white NEUTRAL wire in ceiling fixture outlet box. Secure with wire nut.
- BLACK power wire from fan to RED wire from W-8 in ceiling outlet box. Secure with wire nut.
- BLUE wire from fan to YELLOW wire from W-8 in ceiling outlet box. Secure with wire nut.

NOTE: See Page 10 for additional wiring information.





CANOPY HATCH INSTALLATION

Step 5. Tuck the wires into the canopy with the wire nuts pointed upwards, so that the WHITE and BLACK wires are on opposite sides of the canopy and all wires are clear of the canopy opening.

Step 6. Install canopy hatch with the last canopy screw and lock washer. To do this, tilt the fan body away from the hatch opening.
Tighten the screws firmly by ***hand*** only,

Step 7. Straighten the fan, then check to ensure that there is no movement between the canopy and ceiling or Hang-Tru ball and top support shaft.



BEFORE INSTALLING THE BLADE HOLDERS & BLADES

Step 8. Check your fan and identify if it is a Direct Drive or XLP Motor.



Direct Drive
Blade holders attach directly to the motor unit.



XLP Motor
Blade holders attach to a flexible flywheel.

BLADE HOLDERS & HARDWARE



COMMODORE BLADE HOLDER & BLADE INSTALLATION

Step 8a. Commodore Post Style
Attach the blades to the blade holders with the three countersunk blade screws and cup washers provided for each blade.
Hand tighten securely.

Insert the blade holder shaft into the motor flywheel so that the notch lines up with the brass blade holder screw.
Hand tighten securely.


BLADE SCREW (3 PER BLADE)
CUP WASHER (3 PER BLADE)
BLADE HOLDER INDENTATION
MOTOR FLYWHEEL
BRASS BLADE HOLDER SCREW (1 PER BLADE HOLDER)

CENTER STYLE BLADE HOLDER & BLADE

Step 8b. Center Style
Attach the blades to the blade holders with the four blade screws and steel washers provided for each blade.
Hand tighten securely.

Install the assembled blade and blade holder to the flywheel (round holes) or direct drive motor.
Hand tighten securely.

Repeat for each assembly.



BADGE STYLE BLADE HOLDER & BLADE

Step 8c. Badge Style
Attach the blades to the blade holders by first pressing the blade badge into the blade, then installing the blade holder using the four blade screws provided for each blade.
Hand tighten securely.

Install the assembled blade and blade holder to the flywheel (round holes) or direct drive motor.
Hand tighten securely.

Repeat for each assembly.



CLASSIC STYLE BLADE HOLDER & BLADE

Step 8d. Classic Style
Attach the blades to the blade holders with the three blade screws and felt washers provided for each blade.
Hand tighten securely.

Install the assembled blade and blade holder to the flywheel (round holes) or direct drive motor.
Hand tighten securely.

Repeat for each assembly.



WARNING: To reduce the risk of personal injury, do not bend blade holders when installing, balancing, or cleaning. Do not insert foreign objects between rotating fan blades.

PROCEED TO YOUR FAN'S CONTROL FEATURE SECTION FOR INSTALLATION/OPERATING INSTRUCTIONS:
3-SPEED - PAGE 12 | INTELI•TOUCH - PAGE 14 | VERSA•TOUCH - PAGE 17 | COMFORT•TOUCH - PAGE 19

FAN INSTALLATION OUTSIDE THE USA - EXCLUDING MODELS ENDING IN 'E'

If you do not have an existing fixture located where you wish to place your Casablanca fan, a new ceiling fixture outlet box must be installed (use an outlet box marked acceptable for fan support) and an electrical cable to run it. **This box must be secured to the ceiling according to the outlet box manufacturer's instructions.** It is recommended that this be done by a qualified electrician.

Vaulted or Cathedral Ceiling Installations

Your Casablanca fan may be installed on a vaulted or cathedral ceiling in the same manner as described for a flat ceiling. The Hang-Tru® mounting system makes it possible to hang your fan on sloped ceilings up to a 32 angle.

Using Existing Ceiling Fixture Outlet Box

After turning electrical power off, lower the old fixture to expose the wiring and the ceiling fixture outlet box. Cut the fixture wires or if wire nuts have been used, unscrew them and disconnect the wires. The fixture can then be removed.

After removing the old fixture, check the outlet box to sure that it is supported by a joist or beam across its upper surface. If not, a 2" x 4" stud must be installed.

OUTSIDE USA - SECONDARY SUPPORT INSTALLATION PARTS



OUTSIDE USA - MOUNTING SECONDARY SUPPORT PARTS TO OUTLET BOX

WARNING: MOUNT ONLY TO AN OUTLET BOX MARKED ACCEPTABLE FOR FAN SUPPORT

••••

ADVERTISSEMENT: ASSEMBLER UNIQUEMENT À UNE BÔITE DE SORTIE JUGÉE ACCEPTABLE POUR RETENIR UN VENTILATEUR.

Step 1. Remove the knockout plug in the center of the outlet box or drill a 1/2† hole for the lag screw to pass through. Then drill a 1/4† guide hole into the joist or beam to a depth of 3 inches.

Step 2. Route the outlet box wires through the 1/2† diameter outer hole of the outlet adaptor plate.

Step 3. Line up the slotted holes and four canopy screw holes in the crossbar mounting bracket and outlet adaptor plate with the 8-32 mounting holes in the outlet box. Install the two 8-32 X 2 1/4† (1†) screws and flat washers in fan hardware kit and tighten securely by ***hand*** only!

Step 4. With fender washer and outlet box cable attached as shown, pass lag screw through center hole of outlet adaptor plate and screw into pre drilled 1/4† guide hole of joist. Tighten until outlet box is firmly mounted.

TIP: Threading two of the canopy screws into the crossbar mounting bracket will help everything stay aligned as you tighten the lag screw. Remove them before starting Step 5.



OUTSIDE USA - SECONDARY SUPPORT ♦ CANOPY INSTALLATION

Step 5. Attach the canopy to the crossbar mounting bracket behind the installed outlet adaptor plate with three of the 8-32 x $2^1/_2$† long canopy screws and lock washers provided with your Casablanca fan. Hand tighten until snug against the ceiling.
Note: On sloped ceilings, align the canopy opening toward the top or peak of the room.



Step 6. Attach the spring lock hook to the fan cable by depressing the spring lock and clipping onto the loop at the end.



OUTSIDE USA - SECONDARY SUPPORT ♦ HANGING THE FAN

Step 7. To hang the fan body in the canopy, hold the fan body firmly and insert the nylon ball into the canopy opening. Rotate fan body until slot on nylon ball fits into pin opposite canopy opening.

Step 8. Attach the fan wires to the ceiling outlet box wiring by twisting the bare ends of the wiring together:

- White wire from fan to white NEUTRAL wire in ceiling outlet box.
- Black wire and blue wire (3-Speed fan only) from fan to black (or red) POWER wire in ceiling outlet box.
- Green leads from crossbar mounting bracket and fan to grounding conductor of power source.

Secure by threading on the wire nuts provided with the fan.



OUTSIDE USA - SECONDARY SUPPORT ♦ COMPLETING INSTALLATION

Step 9. Attach the fan cable to outlet box cable with the spring lock hook. Make sure the spring lock is tightly closed.

Step 10. Tuck the wires into the canopy with the wire nuts pointed upward, so that the white and black wires are on opposite sides of the canopy and all wires are clear of the canopy opening. Tuck the extra cable and screw lock hook into the canopy.



NOTE: *International fans and light fixtures are supplied with plug and socket connectors. Substitute these connectors for the wire nuts shown throughout this manual.*



RETURN TO YOUR FAN INSTALLATION INSTRUCTIONS AND CONTINUE WITH THE 'CANOPY HATCH INSTALLATION' SECTION ON PAGE 7.

3-SPEED ✦ W-4 WALL CONTROL OF THE FAN

- The W-4 allows the choice of four (4) different speed settings.
- No light fixture is used.
- Set the FAN pull chain switch to the HIGH speed setting.
- No changes in household or fan wiring are required.
- The fan may be turned ON and OFF by the W-4 wall control.

CAUTION! Failure to set the pull-chain speed to HIGH can result in faulty operation of the fan and damage to the W-4 wall control. To confirm fan is set to HIGH: Turn W-4 fan speed switch to 'HI' - set fastest fan speed with pull chain.



3-SPEED ✦ W-8 WALL CONTROL OF THE FAN & LIGHT(S)

- The fan may be turned ON and OFF by the W-8 wall control.
- The lights may be turned ON and OFF by the W-8 and the intensity adjusted from low to high.
- The fan must be supplied with two independent 120V AC supply wires.
- Set the FAN pull chain switch to the HIGH speed setting.
- Turn the lights ON at the fan.
- The W-8 allows the choice of four (4) different speed settings.

CAUTION! Failure to set the pull-chain speed to HIGH can result in faulty operation of the fan and damage to the W-8 wall control. To confirm fan is set to HIGH: Turn W-8 fan speed switch to 'HI' - set fastest fan speed with pull chain.



3-SPEED ✦ OPERATION

Pull-chain switches on the fan control the fan and lights.
Using the fan control pull-chain switch: Fan off at start.
First pull: fan ON, low speed
Second pull: medium speed
Third pull: high speed
Fourth pull: fan OFF
Using the optional light pull-chain switch: Light off at start.
First pull: light ON
Second pull: light OFF
Direction of blade rotation is controlled by the reverse slide switch on the side of the switch housing.
No changes in household wiring are required.



3-SPEED ✦ OPTIONAL LIGHT FIXTURE INSTALLATION

NOTE: *If a separate circuit is used to control the lights from a wall control, the BLUE D1-Option wire in the canopy should be connected to that switch leg with the BLACK fan power wire.*

1. Refer to light kit instructions to assemble and attach your light kit correctly.
2. Remove the two 8-32 screws from the switch housing cap.
3. Remove the plug from switch housing.
4. Install pull-chain switch and finger tighten collar on switch.
5. Connect one wire from pull-chain switch to the BLUE D1-Option wire. Secure splice with a wire nut.
6. Connect other wire from pull-chain switch to BLACK wire from light kit. Secure splice with a wire nut.
7. Connect WHITE wire from switch housing to WHITE wire from light kit. Secure splice with a wire nut.
8. At the canopy, connect the BLACK and BLUE wires.



3-SPEED ✦ OPTIONAL WALL CONTROL ✦ W-4

The W-4 wall control provides four-speed control of fan from a convenient wall location. The W-4 is designed to replace a standard wall switch and will fit wall boxes with a depth of 2" or greater. ***Not for use with single pull-chain fan/light option wiring.***

To install a W-4 wall control in place of an existing wall switch, follow the instructions on the W-4 package.
Note: No rewiring is required if the fan is replacing an existing light fixture.

Operation of the fan from the wall switch is simple:
1. Turn knob to obtain desired speed setting.

CAUTION! Failure to set the pull-chain speed to HIGH can result in faulty operation of the fan and damage to the W-4 wall control. To confirm fan is set to HIGH: Turn W-4 fan speed switch to 'HI' - set fastest fan speed with pull chain.



3-SPEED ✦ OPTIONAL WALL CONTROL ✦ W-8

The W-8 wall control provides separate control of fan and light with two separate knobs from a convenient wall location. The W-8 is designed to replace a standard wall switch and wall boxes with a depth of 2" or greater. Requires two hot leads from wall box to ceiling wiring box.

To install a W-8 wall control in place of an existing wall switch, follow the instructions on the W-8 package.

Operation of the fan from the wall switch is simple:
1. Turn the upper knob to the desired fan speed.
2. Turn the lower knob to the desired light setting.

CAUTION! Failure to set the pull-chain speed to HIGH can result in faulty operation of the fan and damage to the W-8 wall control. To confirm fan is set to HIGH: Turn W-8 fan speed switch to 'HI' - set fastest fan speed with pull chain.



INTELI•TOUCH © INSTALLING THE W-32 WALL CONTROL

The wall control installs in the same manner as an ordinary light switch, using an existing junction box and wiring. This controller is designed to signal the fan microcomputer as well as perform normal switching operations. For this reason the following precautions must be observed:

1. Use **only** the Casablanca W-32 wall control.
2. Do not use any additional control with your Inteli-Touch fan (for example, dimmer, fan speed control, etc.).
3. Do not use more than **one fan per wall control**.
4. No other light fixtures or electrical appliances may be connected on the circuit controlled by the W-32 wall control.

INTELI•TOUCH ✦ SINGLE W-32 INSTALLATION

CAUTION! Ensure power is turned OFF at the breaker or fuse panel before starting installation.

W-32 is used to describe either white (-11) or ivory finish.

1. Remove the screws and switch plate from the existing switch box.
2. Remove the screws holding the switch in the switch box.
3. Pull the existing switch from the switch box to expose the wire connections.
4. Remove the two wires from the switch.
5. Connect the two wires just removed from the switch to the W-32 wall control black wire and black/white stripe wire. Secure these connections with wire nuts.
6. Install the W-32 in the wall box with the two long screws provided.
7. Install the wall plate with the two color matched screws.

NOTE: *If your wall control operation is reversed, i.e., fan switch controls lights and light switch controls fan, simply swap the two W-32 black/white stripe wires.*



INTELI•TOUCH ✦ DUAL W-32 INSTALLATION

CAUTION! Ensure power is turned OFF at the breaker or fuse panel before starting installation.

To control the fan and lights from two locations (a three-way circuit), use 2 W-32 wall controls.

1. Remove the screws and switch plate from the existing switch box and the screws holding the switch in the switch box.
2. Pull the existing switch from the switch box to expose the wire connections.
3. Determine which wire is connected to the common terminal of the 3-way switch. (The terminal will be marked on switch).
4. Remove the wire from the common terminal of the 3-way switch. Connect this wire to the remaining black/white striped wire on the W-32 control. Secure this splice with a wire nut.
5. Remove the two remaining wires from the 3-way switch. Connect one of these wires to a black wire on the W-32 control. Secure the splice with a wire nut. The remaining wire is to be connected to the other black wire on the W-32. Secure the splice with a wire nut.
6. Install the W-32 in the wall box with the two long screws provided.
7. Install the wall plate with the two short color-matched screws provided.
8. Installation of the second W-32 control is identical. Repeat steps 1 through 7.



NOTE: *If your wall control operation is reversed, i.e., fan switch controls lights and light switch controls fan, simply swap the two W-32 black/white stripe wires.*



INTELI•TOUCH OPERATION ✦ POWER

The POWER button is normally left in the on position. Always turn the power off during cleaning or servicing the fan and during thunderstorms. It is also used to exit or enter additional programs.

POWER *must be left on to retain a previously set fan speed or light level.*



INTELI•TOUCH OPERATION ✦ SPEED CONTROL

There are six individual speed settings for the fan; each speed is indicated by an audible tone of increasing pitch.

To select the desired fan speed:

1. With fan off, press and hold the button labeled FAN**.** The fan blades will start rotating at the slowest speed, and will increase in steps.
2. Release the button when the desired speed is reached.

The fan speed is now in memory and will automatically come on at the same speed each time the FAN button is used. To maintain this level of speed, turn the fan on by pressing FAN less than one second. To lower speed, turn fan off, then on by pressing and holding the FAN button until the desired speed is reached. When the fan is on, you may increase the speed by pressing and holding the FAN button until the desired speed is reached, then release it.

FAN CONTROL

ON - OFF
A momentary press of the FAN button

TO CHANGE SPEED
Press and hold FAN button longer than one second



INTELI•TOUCH OPERATION ✦ REVERSING AIRFLOW

The direction of airflow can be changed from downward to upward or from upward to downward.

To reverse the airflow:

1. Make sure the FAN is on.
2. Press the REVERSE button.

Note: *A four-toned signal indicates the command was accepted by the fan. A few seconds later the fan will slow to a stop and then reverse direction.*



INTELI•TOUCH OPERATION ✦ LIGHT

To turn the lights off and on, press and release the LIGHT button for less than one second.

To vary the light brightness:

1. With lights off, press and hold the LIGHT button. After one second the lights come on at their lowest level and gradually become brighter.
2. Release the button when the desired brightness level is reached.

The brightness level is now in the fan memory and will automatically come on at the same brightness the next time the LIGHT button is used. To maintain this level of brightness, press the LIGHT button for less than one second. To lower the brightness, turn the lights off, then press and hold the LIGHT button until the desired brightness level is reached. When the light is on, you may increase the brightness level by pressing and holding the LIGHT button until the desired level is reached, then release it.

LIGHT CONTROL

ON - OFF
A momentary press of the LIGHT button

TO CHANGE BRIGHTNESS
PRESS AND HOLD LIGHT BUTTON LONGER THAN ONE SECOND



AUTOMATIC DEMONSTRATION PROGRAM

Programmed into every Inteli-Touch Series fan is an Automatic Demonstration Program. It can be used to fully demonstrate and test the operation of the fan.

To enter the demonstration program:

1. Turn POWER off for at least three seconds. This will clear the fan memory ready for programming.
2. Turn POWER on.
3. Immediately operate the buttons in the following sequence:

FAN - LIGHT - FAN - LIGHT - FAN

FAN + LIGHT + FAN + LIGHT + FAN

A multi-tone signal will verify the start of the test program which proceeds as follows:

- Lights slowly increase to full intensity.
- Fan accelerates to speed three with audio tones.
- Light dims to half intensity.
- Fan accelerates to full speed with audio tones.
- Fan reverses at full speed with audio tones.
- Fan operates at full speed.
- Fan power is reversed with audio tones.
- Fan turns off with audio tones (blades coast for a short time).
- Lights turn off.

The complete cycle lasts slightly over one minute. It will continue to repeat until the POWER is turned off for more than three seconds, cancelling the program.

INTELI•TOUCH OPERATION ♦ LIGHT-MINDER® PROGRAM

The Light-Minder program automatically turns OFF the fan mounted lights after two hours.

To enter the Light-Minder Program:

1. Turn the POWER OFF for at least three seconds.
2. Turn the POWER ON.
3. Immediately operate the buttons in the following sequence:
   FAN + FAN + LIGHT + LIGHT
4. A series of tones indicates this command has been accepted.

The fan and light will operate normally using the buttons to turn them on and off. But, if the lights are left on, they will automatically shut off after two hours. To cancel the Light-Minder Program, turn the POWER off for three seconds.



INTELI•TOUCH OPERATION ♦ SAFE-EXIT® PROGRAM

The Safe-Exit Program gives you about thirty seconds of light when you turn the lights off, enabling you to exit your home before the lights go out.

To enter the Safe-Exit Program:

1. Turn the POWER off for at least three seconds.
2. Turn the POWER on.
3. Immediately operate the buttons in the following sequence:
   FAN + FAN + LIGHT + LIGHT

After you hear the confirming audio tones from the fan - ***immediately press*** LIGHT

4. The lights will blink to indicate this command has been accepted.

The lights will stay on for twenty seconds and then begin to dim. After a total of thirty seconds has elapsed, the lights will be off completely. To cancel the Safe-Exit Program, turn the POWER off for three seconds.



Note: *Both Light-Minder and Safe-Exit programs can run at the same time, however the dimmer cannot be used, the light may only be turned ON/OFF.*

INTELI•TOUCH OPERATION ♦ HOME-SAFE® PROGRAM

The Home-Safe Program makes an unoccupied home appear occupied by turning the lights on and off at random times.

To enter the Home-Safe Program:

1. Turn the POWER off for at least three seconds.
2. Turn the POWER on.
3. Immediately operate the buttons in the following sequence:
   LIGHT + FAN + LIGHT + FAN
4. A tone and flashing light indicate this command has been accepted.

This program overrides all manual control of lights and fan. The lights will now be automatically cycled on and off in a controlled sequence as follows: On 1 hour, off 1/2 hour, on 2 hours, off 1 hour, on 1/2 hour then off 2 hours.

This seven hour pattern will repeat continuously so that a different pattern of lighting is seen each day of the week.

To cancel the Home-Safe Program, turn the POWER off for three seconds.

INTELI•TOUCH OPERATION ♦ FAN-MINDER™ PROGRAM

The Fan-Minder feature will add to your comfort when used in the bedroom. The program reduces the speed of the fan each two-hour interval to compensate for the cooling night air.

To enter the Fan-Minder Program:

1. Turn the POWER off for at least three seconds.
2. Turn the POWER on.
3. Immediately operate the buttons in the following sequence:
   LIGHT + LIGHT + FAN + FAN
4. The fan controller will respond with three descending tones. A timer is now initiated and the fan will reduce one speed for each two-hour interval. The fan will not, however, descend below the second lowest speed.

To cancel the Fan-Minder Program, turn the POWER off for three seconds. You may increase the fan speed by pressing and holding the FAN button until the desired speed is reached, then release it. The fan will again reduce one speed for each 2 hour interval.

Fan-Minder (A)



STRONG AIRFLOW

Fan-Minder (B)



GENTLE AIRFLOW

VERSA•TOUCH ♦ INSTALLATION



VERSA•TOUCH ♦ CONTROL HOLDER INSTALLATION

CAUTION! DO NOT USE WITH WALL DIMMER.





Standard Light Switch

Step 1. Remove the two screws holding the switch cover plate. Do not remove the cover plate.
Step 2. Orient the control holder as shown and line up the two inner mounting holes with those on the switch.
Step 3. Install and tighten screws by ***hand*** only.

Rocker Light Switch

Step 1. Break off the two tabs by pushing outward.
Step 2. Remove the two screws holding the switch cover plate. Do not remove the cover plate.
Step 3. Orient the control holder as shown and line up the two outer mounting holes with those on the switch.
Step 4. Install and tighten screws by ***hand*** only.

VERSA•TOUCH ♦ HOLDER INSTALLATION / STORAGE

Wall Installation

Step 1. Locate a 2x4 wall stud in a convenient location.
Step 2. Orient the control holder as shown over the 2x4 stud.
Step 3. Use the 1" wood screws in either the inner or outer mounting holes. Install and tighten screws by ***hand*** only.



Note: *The wall anchors and 6-32 x 1" screws may be used in situations where mounting to a stud is not possible. Use the inner mounting holes. After securing the anchor, discard the anchor's pointed screws and use the 6-32 decor ovalhead screws supplied.*



Control Storage

Angle control in top first until the unit can be gently pushed back and snapped into place.



Removing Control

Gently Pull the lower edge of the control out from the holder.

VERSA•TOUCH ♦ BATTERY INSTALLATION

Remove Battery Door

Turn control on its front. Twist a coin to unsnap the door A. Lift door away from control B and remove C.





Install Battery

Press battery into control aligned as shown. Observe proper polarity. Replace the battery door.



Changes or modifications not expressly approved in writing by Casablanca Fan Co. may void the user's authority to operate this equipment.

This device complies with RSS-210 of Industry Canada. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

VERSA•TOUCH OPERATION

Fan Control

To start the fan. Press the selected speed button to run the fan at the desired speed.

LO **Low speed**
MED **Medium speed**
HI **High speed**

To turn off the fan. Press the **FAN OFF**

button.



Airflow Direction

To reverse the airflow press the **REVERSE** button. Reverse operates at any speed whether fan is on or off. The fan returns to its set speed after reversing.

Light Control

Turn the light on or off independently from the fan by pressing the **LIGHT** button. Keep pressing the button in excess of 0.7 seconds, it becomes a dimmer. The light varies from 'bright' to 'dim' over approximately 8 seconds. This sequence will reverse the light when it reaches the brightest or dimmest level if you continue to hold the **LIGHT** button. Release the button when the desired level is reached.

Auto Resume

Quick (pressing less than 0.7 seconds) on/off operation of the **LIGHT** button maintains the desired brightness level set previously.

VERSA•TOUCH ✦ CONFIRMING CHANNEL DIP SWITCH SETTING - CONTROL

Remote Setting

Step 1. Remove battery.

Step 2. Check that the dip switch in the remote is set to '01110' - as shown.

Step 3. Check that the dip switch in the fan is set the same. (See section below for fan dip switch location)



NOTE: *All fans leave the factory set to '01110'.*

VERSA•TOUCH ✦ CONFIRMING CHANNEL DIP SWITCH SETTING - FAN

NOTE: *If this is the second Versa•Touch fan installed in the same area, one of the fans MUST have its channel changed from '01110' or interference will occur. Make sure that the dip switch settings in both the second remote and second fan are set to the same numbers.*



DIP SWITCH SET TO '01110'



DIP SWITCH SET TO '01001'



Checking Fan Setting

Step 1. Remove the three motor cover screws and lift the motor cover off. Through the view hole on top of the motor, locate the dip switch.

Step 2. Check that the dip switch in the fan and the remote are set to '01110'. If this is a second fan, change the dip switch settings, making sure that the fan and remote are set to the same number.

Step 3. Replace the cover and screws.



W-21 MOUNTING PARTS



REMOTE CONTROL
W-21



REMOTE CONTROL
WALL BRACKET



'AAA' ALKALINE
BATTERY (3)

WALL BRACKET
ANCHOR (4)

WALL BRACKET
SCREW (4)

WALL BRACKET INSTALLATION

Installation of Remote Control
The wall mounting bracket for the remote control should be located in a position that is approximately eye level. Secure the wall mounting bracket with the 1¹/₄† screws or anchors provided, making sure it is level with the floor.

CAUTION! DO NOT MOUNT REMOTE CONTROL ON OR NEAR A METAL SURFACE - ERRATIC OPERATION WILL OCCUR.

Changes or modifications not expressly approved in writing by Casablanca Fan Co. may void the user's authority to operate this equipment.

•••

This device complies with RSS-210 of Industry Canada. Operation is subject ot the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Mount control in convenient location



Remove for handheld or tabletop use

BATTERY INSTALLATION

Battery Installation
Install three 'AAA' alkaline batteries in the sequence shown and replace the battery compartment cover, then press the remote control firmly to the wall bracket so that the Velcro® pads grip the pads on the rear of the control. The remote control can be easily removed at any time should you wish to use it in another location. Just give the control a gentle tug to remove it.

REMEMBER THE REMOTE CONTROL WILL GO BACK TO THE ORIGINAL FACTORY 'PRESET CHANNEL' NUMBER WHEN THE BATTERIES ARE CHANGED. CHANGE CONTROL CHANNEL IF NECESSARY AFTER BATTERY REPLACEMENT.



LOW BATTERY WARNING

Low Battery Indicator
The remote control warns of a low battery condition by displaying a rapidly flashing 'Lo' in place of the temperature display. When this occurs replace with fresh alkaline battery.

WARNING: Use of batteries other than non-leak sealed alkaline in the remote control will void the warranty and can destroy the unit.

Note: *When the remote is in the low battery mode the fan may not respond to control commands correctly even though the fan may be running.*



IMPORTANT OPERATING NOTES

Turning On Your Fan: ***The fan will not receive any signals for the first 20 seconds after power on.*** **This allows the electronics to warm up and stabilize.**

Power Failure: The remote control is not affected by household power failure as it is battery operated. Once power is restored to the fan it will receive an auto-update signal from the remote control within 30 minutes after power is restored. All previously set modes and functions will be restored to the fan.

Button Operation: ***Rapid button pressing causes erratic fan operation.*** For reliable operation of the remote control and fan you must wait **ONE SECOND** between button presses to allow the radio signal to be transmitted to the fan and received.

Labeling: If you have more than one Comfort•Touch fan in your home, we suggest you put an adhesive room identification label on the back of the control. Labels are in the remote control package.



General: Your Comfort•Touch remote control uses one of 15 different radio signals to control the fan. This channel is set at the factory. There may be times when the channel needs to be changed,i.e.:

- Two fans in the house set to the same causing interference.
- Two fans are to be operated from one control.
- Two controls are to operate the same fan - see special 'Dual Remote Control' section on the next page.

TEST PROGRAM

Press the TEST button to activate a two minute program that puts the fan through a complete functional test. The test starts with a full screen display, then the 'preset' channel number before going into a full light, fan and reverse exercise. Follow the remote control LCD display and compare it to the actual fan operation to confirm correct operation.



FAN OPERATION

The Comfort•Touch fan is controlled by the remote control. The fan is turned on and off by alternate pushes of the large right hand button. As with all button operations, an audio tone sounds with each push. With the fan on, the control display will indicate an up or down moving arrow that shows direction and places a box around the operating speed. The two small ▲ and ▼ buttons below the fan button increase or decrease speed once for each press.



LIGHT OPERATION

The light is turned on and off by alternate pushes of the large left hand button. When on, the display will indicate the light bulb symbol and a vertical segment display representing brightness. When the light is on, the brightness may be changed by using the small ▲ and ▼ buttons below the light button. Pressing and holding either button will change the brightness continuously.

Bulb-Saver Feature

When the light is turned on, the brightness is gradually increased until it reaches the preset level. This feature helps extend light bulb life.



ADDITIONAL CONTROL FEATURES

Additional control program features are available from the control panel by opening the control panel door. To activate a control function press the appropriate button; the display will indicate that the program is running.

In some cases you can run more than one program at once, such as SECURITY and SAVER and the display will indicate that they are both activated. In other cases one program will override another as the two programs can not run together i.e. AUTO and WINTER. Full details are explained in the sections that follow.





REVERSE FEATURE

Pressing the REVERSE button will change the direction of rotation. An audio tone signals the beginning of the reverse sequence and you will see the airflow direction arrow changing. The fan gradually slows to a stop, then reverses direction.

Note: *This function does not operate if the fan is not running.*



AUTO-SPEED FEATURE

In the Auto Speed mode, fan speed changes in response to changes in room temperature. Push the AUTO button to start. The words 'AUTO SPEED' show on the display. Set the fan speed to the speed at which you are most comfortable. Once set, the fan will increase or decrease by one speed for each 1.5 F increase or decrease in temperature. If temperature decreases enough to turn the fan OFF, the Auto Speed indicator will flash slowly to remind you that the fan will turn on when the temperature increases.

Note: *The temperature displayed is from an electronic thermometer built into the remote control that reads room temperature. It is not a thermostat that controls the room temperature.*

To cancel Auto Speed, simply push the AUTO button again.
Selecting WINTER also cancels Auto Speed.



TEMPERATURE ACCURACY –3 F

SAVER FEATURE

The Saver mode will automatically turn lights off 1 hour after the lights are turned on. Press the SAVER button and 'SAVER' will appear in the display. An audio tone will warn you 20 seconds before the program is going to turn the lights off. Press the SAVER button again to cancel.



WINTER FEATURE

The Winter mode provides draft-free recirculation of heated air. Press WINTER to activate, and the word 'WINTER' is indicated. This puts the fan in the upward airflow direction at the fan's lowest speed. Every ten minutes the fan will increase to speed 3 for ten seconds before returning to the lowest speed.

Pressing any button on the remote will cancel the 'Winter' mode; except using the light functions.



SECURITY FEATURE

Pressing the SECURITY button will start the Security lighting program. The controller beeps and indicates 'SECURITY'. The light will automatically turn ON and OFF in a seemingly random manner over an eight and a quarter hour programmed cycle that is designed to give the home a "lived-in" look.
Regardless of the light setting when switching to the Security mode (lights on or off, dim or bright), the lights will increase to high brightness and then begin the Security cycle. This cycle is then repeated continuously until cancelled by pressing the SECURITY button.

At any time during the Security mode you may adjust the fan speed, reverse the direction, operate in Auto Speed or Winter, use Saver or run the Test mode without affecting Security mode.

You may still turn the light ON and OFF (or OFF and ON) manually for temporary lighting, but the light will continue to operate automatically at its programmed times.



SECURITY MODE CYCLE

1. On for 30 minutes (80% bright)
2. Off for 30 minutes
3. On for 120 minutes (50% bright)
4. Off for 60 minutes
5. On for 60 minutes (100% bright)
6. Off for 120 minutes
7. On for 15 minutes (20% bright)
8. Off for 60 minutes

COMFORT•TOUCH ✦ CHANGING CHANNELS - CONTROL

Changing the control channel

1. Hold the TEST button down until a tone is heard.
2. The temperature display will show the current channel number.
3. Press fan up ▲ or down ▼ buttons to change the number to a unique number from 49 to 63.
   DO NOT use other channel numbers.
4. Push TEST to return to normal operation.

You will need to repeat this step any time you remove the remote control batteries. Record the new channel setting in the space provided on the rear label.



Note: *Always change the remote control channel first. The fan channel can only be changed by having the desired channel already set in the remote control.*

COMFORT•TOUCH ✦ CHANGING CHANNELS - FAN

1. Turn OFF power to the fan for five seconds or longer using the wall switch or circuit breaker.
2. Turn the power back ON.
   WAIT 20 SECONDS.
   You have 90 seconds in which to complete step 3.
3. Press and hold the TEST and AUTO buttons together until the display shows **'cc'** (for Change Channel), then release.

The control automatically changes the fan channel to the new setting.



Do not reset the channel on other fans in your home during this 110 second period.

COMFORT•TOUCH ✦ DUAL REMOTE CONTROL - BASE

A second remote control can be purchased from your dealer to provide dual remote control of one fan. Because the fan could be confused by two controllers signaling different information it is necessary to set a **BASE** control and an **AUXILIARY** control.
The last control manually operated controls the fan.

Where two remote controls are used to control a single fan, they ***must*** be set so that:

- **BOTH** controls are set to the **SAME** channel.
- **ONE** control is made into the **BASE** control.
- The **OTHER** control is made an **AUXILIARY** control.

(All remote controls leave the factory as a **BASE**).

Initial remote control settings

1. Set ***both*** the controls to operate the fan.
2. Select ***one*** of the remote controls to be the **BASE** unit.



BASE DISPLAY

BASE Check

To confirm that the control is the **BASE**:

1. Press AUTO for 3 seconds until a beep is heard.
2. Confirm temperature display shows **'b'**.
3. Press AUTO again to set.

COMFORT•TOUCH ✦ DUAL REMOTE CONTROL - AUXILIARY

Change the other remote to be used in the room to **AUXILIARY**

1. Press AUTO until a beep is heard. Remote displays **'b'**.
2. Press fan up ▲ or down ▼ buttons to change the display to **'A'**.
3. Press AUTO again to set.

The fan will now respond to either of the remotes when pressed.

- **Reminder! These steps will have to be repeated whenever the batteries are changed.**
- **When AUTO-SPEED, SECURITY, SAVER or TEST modes are in effect at any control: Automatic control will only be from the control that was last operated manually.**



AUXILIARY DISPLAY

TWO CONTROLS OPERATING ONE FAN

When two controls are used for the same fan, we suggest that both controls be set for the same features (AUTO-SPEED, SAVER, etc.) so that performance remains the same as you move from one to the other. Remember, the fan will only respond to updates from the control that was last operated manually.

TROUBLESHOOTING

Before Requesting Service: Please follow this troubleshooting guide before contacting your dealer for assistance.

Caring for Finishes: For cleaning, a soft brush or lint-free cloth should be used to prevent scratching the finish. A vacuum cleaner brush nozzle can remove heavier dust. Surface smudges or an accumulation of dirt and dust can easily be removed by using a mild detergent and slightly dampened soft cloth. An antistatic agent may be used, but ***never*** use abrasive cleaning agents. These will damage the finish. Painted and high-gloss blades may be cleaned in the same manner.

Blades: Wood finish blades should be cleaned with a furniture polishing cloth. Occasionally, a light coat of furniture polish may be applied for added protection and beauty.

Never Lubricate this Fan!

The precision motor at the heart of your Casablanca fan features sealed bearings that are lubricated for life. Do not attempt to oil the motor.

Changing Light Bulbs

Be sure to turn power to the fan OFF at the wall switch or circuit breaker before changing light bulbs. Replace bulbs with same type as removed from the fixture. Each fan is rated for a maximum **TOTAL** wattage of lighting.

Exceeding the rated maximum allowable wattage for the fan will burn out the fan electronics module and void the warranty.

PROBLEM — 3-SPEED — POSSIBLE REMEDIES

FAN WILL NOT START	Check main circuit fuses, circuit breakers, or wall switch position. Check all wire connections, making sure the power is turned off during this inspection. Check that reverse switch is not set in center of throw.
FAN WOBBLES OR SHAKES EXCESSIVELY	Be sure canopy pin is properly set into the slot on the ball. Check the screws holding the blade holders to the flywheel (or direct drive motor). Tighten as necessary. Check that bladeholders have not been bent during installation.
FAN NOISY DURING OPERATION	Check and tighten light fixture retaining screws, glass shade screws and/or the light bulb(s) as neccessary. Tighten the blade to bladeholder screws. Tighten canopy screws and mounting plate assembly. Check and tighten blade holders to flywheel (or direct drive motor). Make sure all screws in the motor housing are snug, but not overly tight. Check that the wire nuts inside the canopy and switch housing are not touching the metal parts or have fallen off the wire splices. Tighten or adjust as necessary.
BREAK-IN PERIOD DOES NOT RUN ON LOW SPEED	Let fan run at high speed for two (2) hours If new, “break-in” may be required - run at higher speed for several days

FAN RUNS SLOWLY IN EITHER DIRECTION IF ROTATION IS STARTED BY HAND; WILL NOT REVERSE: *Defective reverse switch; defective capacitor; or open motor winding: Replace reverse switch assembly; replace PCB assembly; or replace motor unit.*

FAN WILL NOT OPERATE AT PROPER SPEEDS OR WILL NOT OPERATE AT ANY SPEED: *Defective three-speed pull-chain switch assembly; or defective capacitor: Replace three-speed pull-chain switch assembly; or replace PCB assembly.*

PROBLEM — INTELI•TOUCH — POSSIBLE REMEDIES

NO FAN OR LIGHT	Check main circuit fuses, curcuit breakers, or wall switch position. Check all wire connections, making sure the power is turned off during this inspection.
FAN WOBBLES OR SHAKES EXCESSIVELY	Be sure canopy pin is properly set into the slot on the ball Check the screws holding the blade holders to the fan motor. Tighten as necessary. Check the angle of the blades to make sure that a blade holder has not been bent during installation.
FAN NOISY DURING OPERATION	Check and tighten light fixture retaining screws, glass shade screws and/or the light bulb(s). Tighten canopy screws and mounting plate assembly. Tighten the blade to bladeholder screws and blade holders to flywheel. Make sure all screws in the motor housing are snug, but not overly tight. Check that the wire nuts inside the canopy and switch housing are not touching the metal parts or have fallen off the wire splices. Tighten or adjust as necessary.
BREAK-IN PERIOD DOES NOT RUN ON LOW SPEED	Let fan run at high speed for two (2) hours If new, “break-in” may be required - run at higher speed for several days

LIGHTS FLASH OR BLINK DURING OPERATION OF W-32 WALL CONTROLS/FAN MAY ROTATE OR MAKE AUDIBLE TONES DURING OPERATION OF THE W-11 AND W-12 WALL CONTROLS: *Normal operation.*

WHEN AC POWER IS TURNED ON FOR THE FIRST TIME, THE LIGHTS OPERATE NORMALLY, BUT W-32 WALL CONTROL OPERATION IS REVERSED: FAN BUTTON OPERATES THE LIGHTS; LIGHT BUTTON OPERATES THE FAN: *Reverse the 2 black and white striped wire connections.*

FAN OR LIGHTS APPEAR TO OPERATE BY THEMSELVES (CHANGING SPEED OR INTENSITY), WALL CONTROL OPERATION IS INTERMITTENT: *Check AC supply for irregularities, (noise spikes, fluctuations, or failure); or circuit board assembly.*

PROBLEM	VERSA•TOUCH	POSSIBLE REMEDIES
FAN WILL NOT START	Check main circuit fuses, circuit breakers, or wall switch position. Check all wire connections, making sure the power is turned off during this inspection. Pin connectors are not making good contact. Release lockpin and check pins at end of downrod & inside coupler and also 9 pin connector under cover. Battery weak - install fresh battery. Fan receiver defective - replace. Check the receiver and transmitter dip switch to see if they are on the same frequency setting.	
FAN WOBBLES OR SHAKES EXCESSIVELY	Be sure canopy pin is properly set into the slot on the ball. Check that bladeholders have not been bent during installation and blades are balanced. Hanger bracket and/or ceiling outlet are loosely attached: Make sure that the hanger bracket is tightly attached to the ceiling outlet box. Make sure that the downrod assembly is secured firmly Downrod is loosely attached to downrod base: Make sure that all screws are securely tightened	
FAN NOISY DURING OPERATION	Check and tighten light fixture retaining screws, glass shade screws and/or the light bulb(s). Tighten canopy screws and mounting plate assembly. Check that the wire nuts inside the canopy and switch housing are not touching the metal parts or have fallen off the wire splices. Tighten as necessary. Tighten blade holders to flywheel (or direct drive motor)/and blade to bladeholder screws. Make sure all screws in the motor housing are snug, but not overly tight. Defective bulb: Replace bulb.	
DOES NOT RUN ON LOW SPEED	If new, "break-in" may be required - run at higher speed for several days.	
BATTERY LIFE SEEMS SHORT	Not using Alkaline batteries: Replace with Alkaline batteries.	

LIGHT O.K., NO FAN: *Pin connectors are not making good contact, check 9 pin connector under top cover.* ***FAN O.K., NO LIGHT;*** *Defective receiver; Replace receiver. Defective motor; Replace motor. Broken socket; Replace socket. Defective receiver; Replace Receiver.* ***FAN AND LIGHT ON FULL, NO CONTROL;*** *Defective receiver; Replace Receiver.* ***MISSING ONE SPEED:*** *Defective receiver; ReplaceReceiver.* ***FAN DOESN'T CHANGE SPEED, LIGHT O.K.:*** *Replace receiver.* ***FAN O.K., LIGHT NOT DIM:*** *Defective receiver; Replace Receiver.* ***NO REVERSE:*** *Defective receiver; Replace Receiver.* ***FAN OPERATES ONLY WHEN TRANSMITTER IS CLOSED:*** *Check antenna wire is not touching metal plate.* ***FAN STARTS WORKING BY ITSELF:*** *Frequency interference; Change dip switch code.*

PROBLEM	COMFORT•TOUCH	POSSIBLE REMEDIES
FAN O.K., NO LIGHT	Check for burned-out light bulb. Check fan light wires.	
REMOTE CONTROL OF FAN IS ERRATIC	Check batteries installed correctly. Install fresh ALKALINE batteries.	
SELECTING WINTER MODE CANCELS AUTO-SPEED	Normal.	
CHANGING SPEED OR DIRECTION CANCELS WINTER	Normal.	
FAN APPEARS TO RESPOND TO UNKNOWN SIGNAL	Change channel of control and fan to a number between 49 and 63.	
CONTROL ALSO OPERATES A SECOND FAN IN HOME	Change channel on control and fan.	
TEMPERATURE DISPLAY DOES NOT CHANGE QUICKLY	Normal. Updates only every 2 minutes.	
FAN WOBBLES OR SHAKES EXCESSIVELY	Make sure hanging ball slot is properly aligned. Tighten canopy and mounting crossbar screws. Tighten all blade screws. Blades must be balanced (contact your dealer).	
FAN NOISY DURING OPERATION	Tighten glassware and light bulbs. Tighten motor housing screws. Tighten canopy and mounting crossbar screws.	
DOES NOT RUN ON LOW SPEED	If new, "break-in" may be required - run at higher speed for several days.	
BATTERY LIFE SEEMS SHORT	Not using Alkaline batteries: Replace with Alkaline batteries.	
TEMPERATURE READINGS	Temperature accuracy = – 3 F	

FAN DOES NOT RESPOND TO REMOTE CONTROL: *Power to fan is off; wrong remote being used; remote channel changed; fan receive SET channel changed; or fan antenna not receiving. See above; in locations with two or more fans in different rooms check that controllers are in right rooms; change SET channel to match fan; change fan SET channel to match remote; check antenna connected to RCM; check antenna positioned correctly; if batteries weak by moving remote close to fan; check that remote not laying on metal surface causing weak signal; or connect Earth ground to fan.*

FAN APPEARS TO RESPOND TO UNKNOWN SIGNAL OR IS ERRATIC: *Invalid lower channel SET; 2nd remote in area SET to same channel; or remote buttons pressed too quickly Be sure SET channel is between 49 and 63; check SET channels of any other remotes at site (check if nearby homes have Comfort Touch fans installed- remote signal can travel 50 ft.); and for proper operation of the control you must wait "one second" between presses.*

AFTER POWER FAILURE, FAN AND LIGHTS ARE OFF: *Normal: To immediately restore fan to its original settings press any button. Fan will reset itself within about 30 minutes after power is restored when remote sends normal update message to fan.*

WHEN AC POWER IS TURNED ON, LIGHT COMES ON OR FAN TURNS: *Remote control defective; remote buttons pressed too soon; AC electricity irregularities (noise spikes, fluctuations, or failure). Turn off with remote and restart; replace remote control unit; or wait twenty seconds for electronics warm-up; check AC electricity for irregularities (defective light dimmers, noise spikes, voltage changes caused by appliances, motors, supply brown outs or interruptions, or storms, etc).*

PRINTED IN ROC